

Everything's possible.

DigiFlex[®] Performance[™] DZM Drives

Click&Move[®] Embedded
Hardware
Installation Manual

ADVANCED Motion Controls constantly strives to improve all of its products. We review the information in this document regularly and we welcome any suggestions for improvement. We reserve the right to modify equipment and documentation without prior notice.

For the most recent software, the latest revisions of this manual, and copies of compliance and declarations of conformity, visit the company's website at www.a-m-c.com. Otherwise, contact the company directly at:

ADVANCED Motion Controls • 3805 Calle Tecate Camarillo, CA • 93012-5068 USA

Agency Compliances

The company holds original documents for the following:

- UL 508c, file number E140173
- Electromagnetic Compatibility, EMC Directive - 2014/30/EU
EN61000-6-2:2005
EN61000-6-4:2007/A1:2011
- Electrical Safety, Low Voltage Directive - 2014/35/EU
EN 60204-1:2006/A1:2009
- Reduction of Hazardous Substances (RoHS III), 2015/863/EU
- Functional Safety Type Approved, TUV Rheinland

Trademarks

ADVANCED Motion Controls®, the combined isosceles trapezoid/right triangle logo, **DIGIFLEX®**, **DIGIFLEX® Performance™**, Click&Move®, and DriveWare® are either registered trademarks or trademarks of *ADVANCED* Motion Controls in the United States and/or other countries. All other trademarks are the property of their respective owners.

Related Documentation - available for download at www.a-m-c.com

- Product datasheet specific for your drive
- DriveWare Software Startup Guide

Attention Symbols

The following symbols are used throughout this document to draw attention to important operating information, special instructions, and cautionary warnings. The section below outlines the overall directive of each symbol and what type of information the accompanying text is relaying.



Note

Note - Pertinent information that clarifies a process, operation, or ease-of-use preparations regarding the product.



Notice

Notice - Required instruction necessary to ensure successful completion of a task or procedure.



Caution

Caution - Instructs and directs you to avoid damaging equipment.



Warning

Warning - Instructs and directs you to avoid harming yourself.



DANGER

Danger - Presents information you must heed to avoid serious injury or death.

Revision History

Document ID	Revision #	Date	Changes
MNDGZMIN-01	1	5/2016	DZMANTU Install Manual First Release
MNDGZMIN-02	2	5/2018	Added 2-phase Stepper Motor Information

© 2018 *ADVANCED* Motion Controls. All rights reserved.

1 **Safety** **1**

1.1 General Safety Overview	1
-----------------------------------	---

2 **Products and System Requirements** **4**

2.1 DZMANTU Drive Overview	4
2.2 Products Covered	5
2.3 Communication Protocol	6
2.4 Control Modes	7
2.4.1 Current (Torque)	7
2.4.2 Velocity	7
2.4.3 Position	7
2.5 Feedback Supported	8
Feedback Polarity	8
2.5.1 Incremental Encoder Feedback	8
2.5.2 Absolute Encoder	9
2.5.3 1Vp-p Sin/Cos Encoder	10
2.5.4 Hall Sensors	10
2.5.5 Auxiliary Incremental Encoder	11
2.5.6 Tachometer (± 10 VDC)	11
2.5.7 ± 10 VDC Position	11
2.6 Command Sources	12
2.6.1 Embedded Click&Move® Program	12
2.6.2 ± 10 V Analog	12
2.6.3 Encoder Following	12
2.7 Pinouts and Pin Layouts	13
2.7.1 DZMANTU	13

2.8 System Requirements	14
2.8.1 Specifications Check	14
2.8.2 Motor Specifications	14
2.8.3 Power Supply Specifications	15
2.8.4 Environment	16
Ambient Temperature Range and Thermal Data	16
Shock/Vibrations	17

3 Integration in the Servo System **18**

3.1 LVD Requirements	18
3.2 CE-EMC Wiring Requirements	19
General	19
Analog Input Drives	19
PWM Input Drives	19
MOSFET Switching Drives	19
IGBT Switching Drives	19
Fitting of AC Power Filters	19
3.2.1 Ferrite Suppression Core Set-up	20
3.2.2 Inductive Filter Cards	20
3.3 Grounding	21
3.4 Wiring	22
3.4.1 Wire Gauge	22
3.4.2 Motor Wires	22
3.4.3 Power Supply Wires	23
3.4.4 Feedback Wires	23
3.4.5 Input Reference Wires	24
3.4.6 Communication Wires	24
3.5 Mounting	25
3.5.1 Mounting Card	25
MC1XDZPE01 Mounting Standoffs	25
Mating Connector Kit	26
3.6 PCB Design	27
3.6.1 Trace Width and Routing	27
3.6.2 PCB Mounting Options	27
Mating Connectors	27
Soldering	28
Screw Mounting	28
3.6.3 Interface Circuitry Examples	29

Address Line Inputs	29
Digital Inputs (Standard)	29
Digital Inputs (High Speed)	30
Digital Outputs	30
Analog Inputs	30
Hall Sensor Inputs	31
Encoder Inputs	32
Auxiliary Encoder	33
Logic Supply Input	34
DC Power Input	34
Motor Power Output	35
STO (Safe Torque Off) Interface	36
Ethernet Interface	38
USB Interface	39
Drive Status LEDs	40
Motor Thermistor Input	40

4 Operation and Features **41**

4.1 Features and Getting Started	41
4.1.1 Initial Setup and Configuration	41
4.1.2 Input/Output Pin Functions	43
Ethernet Node Address Selector	43
Motor Thermistor	43
Programmable Digital Inputs	43
Programmable Digital Outputs	43
Programmable Analog Input	43
4.1.3 Ethernet Communication LEDs Functionality	44
4.1.4 Commutation	44
Sinusoidal Commutation	44
Trapezoidal Commutation	45
4.1.5 Firmware	46

A Specifications **47**

A.1 Specifications Tables	47
A.2 Mounting Dimensions	49

B Troubleshooting **50**

B.1 Fault Conditions and Symptoms	50
Over-Temperature	50
Over-Voltage Shutdown	50
Under-Voltage Shutdown	50
Short Circuit Fault	51
Invalid Hall Sensor State	51
B.1.1 Software Limits	51
B.1.2 Connection Problems	51
B.1.3 Overload	52
B.1.4 Current Limiting	52
B.1.5 Motor Problems	52
B.1.6 Causes of Erratic Operation	52
B.2 Technical Support	53
B.2.1 Drive Model Information	53
B.2.2 Product Label Description	53
B.2.3 Warranty Returns and Factory Help	54

Index I

This section discusses characteristics of your DZMANTU DigiFlex® Performance™ Drive to raise your awareness of potential risks and hazards. The severity of consequences ranges from frustration of performance, through damage to equipment, injury or death. These consequences, of course, can be avoided by good design and proper installation into your mechanism.

1.1 General Safety Overview

In order to install a DZMANTU drive into a servo system, you must have a thorough knowledge and understanding of basic electronics, computers and mechanics as well as safety precautions and practices required when dealing with the possibility of high voltages or heavy, strong equipment.

Observe your facility's lock-out/tag-out procedures so that work can proceed without residual power stored in the system or unexpected movements by the machine.



Notice

You must install and operate motion control equipment so that you meet all applicable safety requirements. Ensure that you identify the relevant standards and comply with them. Failure to do so may result in damage to equipment and personal injury.

Read this entire manual prior to attempting to install or operate the drive. Become familiar with practices and procedures that allow you to operate these drives safely and effectively. You are responsible for determining the suitability of this product for the intended application. The manufacturer is neither responsible nor liable for indirect or consequential damages resulting from the inappropriate use of this product.



Caution

Over current protective devices recognized by an international safety agency must be installed in line before the servo drive. These devices shall be installed and rated in accordance with the device installation instructions and the specifications of the servo drive (taking into consideration inrush currents, etc.). Servo drives that incorporate their own primary fuses do not need to incorporate over current protection in the end user's equipment.



Notice

High-performance motion control equipment can move rapidly with very high forces. Unexpected motion may occur especially during product commissioning. Keep clear of any operational machinery and never touch them while they are working.



Warning

Keep clear of all exposed power terminals (motor, DC Bus, shunt, DC power, transformer) when power is applied to the equipment. Follow these safety guidelines:

- When using a separate logic supply, turn on the logic power supply first before turning on the main power supply.
- Always turn off the main power and allow sufficient time for complete discharge before making any connections to the drive.
- Do not rotate the motor shaft without power. The motor acts as a generator and will charge up the power supply capacitors through the drive. Excessive speeds may cause over-voltage breakdown in the power output stage. Note that a drive having an internal power converter that operates from the high voltage supply will become operative.
- Do not short the motor leads at high motor speeds. When the motor is shorted, its own generated voltage may produce a current flow as high as 10 times the drive current. The short itself may not damage the drive but may damage the motor. If the connection arcs or opens while the motor is spinning rapidly, this high voltage pulse flows back into the drive (due to stored energy in the motor inductance) and may damage the drive.
- Do not make any connections to any internal circuitry. Only connections to designated connectors are allowed.
- Do not make any connections to the drive while power is applied.



Caution

- Do not reverse the power supply leads! Severe damage will result!
- If using relays or other means to disconnect the motor leads, be sure the drive is disabled before reconnecting the motor leads to the drive. Connecting the motor leads to the drive while it is enabled can generate extremely high voltage spikes which will damage the drive.



Caution

Use sufficient capacitance!

Pulse Width Modulation (PWM) drives require a capacitor on the high voltage supply to store energy during the PWM switching process. Insufficient power supply capacitance causes problems particularly with high inductance motors. During braking much of the stored mechanical energy is fed back into the power supply and charges its output capacitor to a higher voltage. If the charge reaches the drive's over-voltage shutdown point, output current and braking will cease. At that time energy stored in the motor inductance continues to flow through diodes in the drive to further charge the power supply capacitance. The voltage rise depends upon the power supply capacitance, motor speed, and inductance.



Caution

Make sure minimum inductance requirements are met!

Pulse Width Modulation (PWM) servo drives deliver a pulsed output that requires a minimum amount of load inductance to ensure that the DC motor current is properly filtered. The minimum inductance values for different drive types are shown in the individual data sheet specifications. If the drive is operated below its maximum rated voltage, the minimum load inductance requirement may be reduced. Most servo-motors have enough winding inductance. Some types of motors (e.g. "basket-wound", "pancake", etc.) do not have a conventional iron core rotor, so the winding inductance is usually less than 50 μH .

If the motor inductance value is less than the minimum required for the selected drive, use an external filter card.



Products and System Requirements

This document is intended as a guide and general overview in selecting, installing, and operating a pcb-mount DigiFlex[®] Performance[™] digital servo drive with embedded Click&Move[®] functionality. These specific drives are referred to herein and within the product literature as DZM or DZMANTU drives, interchangeably. Contained within are instructions on system integration, wiring, drive-setup, and standard operating methods.

2.1 DZMANTU Drive Overview

DZMANTU digital drives are designed to offer the same high performance and accuracy of larger drives, but in a space-saving PCB-mount architecture. By utilizing high density power devices, dual-sided PCB boards, and creative design DZMANTU drives are ideal for applications with limited size and weight constraints.

The DZMANTU drive family can power three phase or single phase brushless or brushed servomotors, two phase or three phase closed loop stepper motors, and closed loop vector AC induction motors. DZMANTU drives are powered off a single isolated DC power supply, and provide a variety of control and feedback options. A digital controller can be used to command and interact with the drives, and a number of dedicated and programmable digital and analog input/output pins are available for parameter observation and drive configuration. DZMANTU drives are capable of operating in Current, Velocity or Position Mode, and utilize Space Vector Modulation, which results in higher bus voltage utilization and reduced heat dissipation compared to traditional PWM.

DZMANTU drives feature an Ethernet interface for network communication and USB connectivity for drive configuration and setup. Drive commissioning is accomplished using DriveWare[®] 7, the setup software from *ADVANCED* Motion Controls, available for download at www.a-m-c.com.

Click&Move[®] motion control and automation programs can be executed using these drives. User variables in a Click&Move embedded project can also be stored in non-volatile memory. Click&Move is available for download and purchase at www.a-m-c.com.

The drive datasheet contains important information on the options and product-specific features available with that particular drive. The datasheet is to be used in conjunction with this manual for system design and installation and can be downloaded from www.a-m-c.com.

2.2 Products Covered

The products covered in this manual adhere to the following part numbering structure. However, additional features and/or options are readily available for OEM's with sufficient ordering volume. Feel free to contact *ADVANCED* Motion Controls for further information.

FIGURE 2.1 DZMANTU Part Numbering Structure




TABLE 2.1 Power Specifications

Description	Units	020B080	040B080	020B200
DC Supply Voltage Range	VDC	18-80		40-175
DC Bus Over Voltage Limit	VDC	89 (-5%)		193 (-3%)
DC Bus Under Voltage Limit	VDC	16 (±7.5%)		37 (±7.5%)
Logic Supply Voltage	VDC	18-80 (optional)		40-175 (optional)
Maximum Peak Output Current ¹	A (A _{rms})	20 (14.1)	40 (28.3)	20 (14.1)
Maximum Continuous Output Current	A (A _{rms})	10 (10)	20 (20)	10 (10)
Maximum Continuous Output Power	W	760	1520	1663
Maximum Power Dissipation at Continuous Current	W	40	80	88
Internal Bus Capacitance ²	μF	33	33	7
Minimum Load Inductance ³	μH	250		
Switching Frequency	kHz	20		
Maximum Output PWM Duty Cycle	%	85		

1. Capable of supplying drive rated peak current for 2 seconds with 10 second foldback to continuous value. Longer times are possible with lower current limits.

2. Additional 100μF / 100V external bus capacitor required for 020B080 and 040B080 drive models, and 100μF / 200V for 020B200 drive models.

3. Lower inductance is acceptable for bus voltages well below minimum. Use external inductance to meet requirements.

TABLE 2.2 Control Specifications

Description	DZMANTU
Network Communication	Modbus TCP / Ethernet (USB for configuration)
Command Sources	Embedded Click&Move®, ±10V Analog, Over the Network
Commutation Methods	Sinusoidal, Trapezoidal
Control Modes	Current, Velocity, Position
Motors Supported	Three Phase (Brushless Servo), Single Phase (Brushed Servo, Voice Coil, Inductive Load), Stepper (2- or 3-Phase Closed Loop), AC Induction (Closed Loop Vector)
Hardware Protection	40+ Configurable Functions, Over Current, Over Temperature (Drive & Motor), Over Voltage, Short Circuit (Phase-Phase & Phase-Ground), Under Voltage
Programmable Digital I/O	8 Inputs, 5 Outputs
Programmable Analog I/O	1 Input
Feedback Supported	Hall Sensors, Incremental Encoder, Aux. Incremental Encoder, 1Vp-p Sine/Cosine Encoder, Absolute Encoder (EnDat® 2.1, Hiperface®, or BiSS C-Mode), ±10 VDC Position, Tachometer (±10 VDC)

2.3 Communication Protocol



Ethernet

DZPANTU digital drives offer networking capability through Modbus TCP or Ethernet communication. An auxiliary USB port is featured for configuring the drive through DriveWare.

Modbus is an open standard, master slave system developed for communication between multiple devices using a single wire. The Modbus protocol uses a defined message structure, regardless of the physical layer of the network used to communicate. A master device initiates a "query", and slave devices return a "response", supplying the requested data or taking the requested action. The query can be made to individual devices or broadcast to all connected devices. For more detailed information on Modbus TCP communication with DZPANTU drives and a complete list of register definitions, consult the *ADVANCED* Motion Controls' Modbus Communication Manual available for download at www.a-m-c.com.

The Modbus TCP protocol for *ADVANCED* Motion Controls' DZPANTU drives follows the Modbus Application Protocol Specification V1.1b. More information can be found at www.Modbus-IDA.org.

2.4 Control Modes

DZMANTU digital drives operate in either Current, Velocity or Position Mode. The setup and configuration parameters for these modes are commissioned through DriveWare. See the DriveWare Software Manual for mode configuration information.

2.4.1 Current (Torque)

In Current (Torque) Mode, the input command voltage controls the output current. The drive will adjust the output duty cycle to maintain the commanded output current. This mode is used to control torque for rotary motors (force for linear motors), but the motor speed is not controlled. The output current and other parameters can be monitored in DriveWare through the digital oscilloscope function. DriveWare also offers configuration of maximum and continuous current limit values.



Note

While in Current (Torque) Mode, the drive will maintain a commanded torque output to the motor based on the input reference command. Sudden changes in the motor load may cause the drive to output a high torque command with little load resistance, causing the motor to spin rapidly. Therefore, Current (Torque) Mode is recommended for applications using a digital position controller to maintain system stability.

2.4.2 Velocity

In Velocity Mode, the input command controls the motor velocity. This mode requires the use of a feedback element to provide information to the drive about the motor velocity. The motor velocity and other parameters can be monitored within the configuration software, or externally through network commands. See [“Feedback Supported” on page 8](#) for more information on velocity feedback devices.

2.4.3 Position

In Position Mode, the input command controls the actual motor position. This mode requires the use of a feedback element to provide information to the drive about the physical motor location. The motor position and other parameters can be monitored within the configuration software, or externally through network commands. See [“Feedback Supported” on page 8](#) for more information on position feedback devices.

2.5 Feedback Supported

DZMANTU drives feature the ability to support a variety of primary feedback devices by downloading the appropriate firmware into the drive. Compatible firmware-dependent devices are Incremental Encoders, Absolute Sin/Cos Encoders (Hiperface® and EnDat®), and 1Vp-p Sin/Cos Encoders. Consult the DriveWare Software Manual for instructions on how to download firmware into a digital servo drive.

Other supported feedback types that do not require a firmware change are Hall Sensors, Auxiliary Incremental Encoder, Tachometer, and ± 10 VDC Position feedback.

Feedback Polarity The feedback element must be connected for *negative* feedback. This will cause a difference between the command signal and the feedback signal, called the *error signal*. The drive compares the feedback signal to the command signal to produce the required output to the load by continually reducing the error signal to zero. This becomes important when using encoder or Hall Sensor feedback, as connecting these feedback elements for positive feedback will lead to a motor "run-away" condition. In a case where the feedback lines are connected to the drive with the wrong polarity, the drive will attempt to correct the "error signal" by applying more command to the motor. With the wrong feedback polarity, this will result in a positive feedback run-away condition. To correct this, either change the order that the feedback lines are connected to the drive, or use DriveWare to reverse the internal velocity feedback polarity setting. The AutoCommutation routine in DriveWare will typically determine the proper feedback polarity setting.

2.5.1 Incremental Encoder Feedback

DZMANTU drives can utilize differential incremental encoder inputs for velocity or position control, with the option of also using the encoder to commutate the motor. The encoder provides incremental position feedback that can be extrapolated into very precise velocity or position information. With an Encoder being used as the feedback element, the input command controls the motor velocity or motor position, with the frequency of the encoder signal closing either the velocity or position loop. The encoder signals are read as "pulses" that the drive uses to essentially keep track of the motor's speed, position and direction of rotation. Based on the speed and order in which these pulses are received from the encoder, the drive can interpret the motor velocity and physical location. The actual motor speed and physical location can be monitored in DriveWare through the digital oscilloscope function. Both the "A" and "B" channels of the encoder are required for operation. DZMANTU drives also accept an optional differential "index" channel that can be used for synchronization and/or homing.




Note

Users designing their own PCB interface may also design the appropriate circuitry on their PCB interface to allow single-ended inputs. See ["Encoder Inputs" on page 32](#) for circuitry recommendation.

Figure 2.2 below represents differential encoder "pulse" signals, showing how dependent on which signal is read first and at what frequency the "pulses" arrive, the speed and direction of the motor shaft can be extrapolated. By keeping track of the number of encoder "pulses" with

respect to a known motor "home" position, DZMANTU drives are able to ascertain the actual motor location.

FIGURE 2.2 Encoder Feedback Signals



DZMANTU drives can also use encoder feedback for sinusoidal commutation by using the AutoCommutation routine in DriveWare. Encoder feedback is also used in the "Phase Detect" procedure in DriveWare, which is necessary when using a three phase (brushless) motor without Hall Sensors. Phase Detect works by sending a small current signal to the motor, prompting the motor to vibrate slightly for a few seconds. The encoder feedback from this movement provides a starting position for the motor, allowing the drive to then be properly commutated. See the Driveware Software Guide for more information on Phase Detect.



Note

The high resolution of motor mounted encoders allows for excellent velocity and position control and smooth motion at all speeds. Encoder feedback should be used for applications requiring precise and accurate velocity and position control, and is especially useful in applications where low-speed smoothness is the objective.

2.5.2 Absolute Encoder

DZMANTU drives support Hiperface®, EnDat® (2.1 command set), or BiSS C-Mode absolute encoders for velocity and absolute position feedback. The encoder resolution and other options can be configured within the configuration software. The drive breaks down the signals from the encoder into individual reference points (counts). For feedback devices that


accept 1 Vp-p signals, the interpolation is configurable in powers of 2 from 1 to 512 lines per Sin/Cos cycle. The quadrature number of counts per cycle is the interpolation value multiplied by 4, as shown in [Figure 2.3](#). This allows for very high interpolated encoder resolution (4-2048 counts per cycle).



Note

The absolute position feedback eliminates the need for a homing routine when the drive is powered on.

FIGURE 2.3 Sin/Cos Encoder Interpolation



2.5.3 1Vp-p Sin/Cos Encoder

DZMANTU drives support 1Vp-p Sin/Cos encoders for position and velocity feedback. The drive breaks down the 1Vp-p sinusoidal signals from the encoder into individual reference points (counts). The interpolation is configurable in powers of 2 from 1 to 512 lines per Sin/Cos cycle. The quadrature number of counts per cycle is the interpolation value multiplied by 4, as shown in [Figure 2.3](#). This allows for very high interpolated encoder resolution (4-2048 counts per Sin/Cos cycle).

2.5.4 Hall Sensors

DZMANTU drives can use single-ended Hall Sensors for commutation and/or velocity control. The Hall Sensors (typically three) are built into the motor to detect the position of the rotor magnetic field. With Hall Sensors being used as the feedback element, the input command voltage controls the motor velocity, with the Hall Sensor frequency closing the velocity loop. The Hall Sensor frequency is converted into velocity feedback that the drive uses to control the motor speed and direction. The actual motor speed can be monitored in DriveWare through the digital oscilloscope function.



Note

Due to the inherent low resolution of motor mounted Hall Sensors, using Hall Sensors for velocity feedback is not recommended for low-speed applications below 300 rpm for a 6-pole motor, 600 rpm for a 4-pole motor, or 900 rpm for a 2-pole motor. Hall Velocity Mode is better suited for velocity control applications where the motor will be spinning at higher speeds.

For more information on using Hall Sensors for trapezoidal commutation, see [“Trapezoidal Commutation” on page 45](#).

2.5.5 Auxiliary Incremental Encoder

The auxiliary encoder input pins can be used as a command source for encoder following mode, or as a secondary feedback device input for closing the position loop. The particular function is configured in DriveWare.

2.5.6 Tachometer (± 10 VDC)

DZMANTU drives support the use of a tachometer for velocity feedback. The tachometer measures the rotary speed of the motor shaft and returns an analog voltage signal to the drive for velocity control. DZMANTU drives provide a Programmable Analog Input on the motor Feedback Connector that is available for use with a tachometer. The tachometer signal is limited to ± 10 VDC.

2.5.7 ± 10 VDC Position

DZMANTU drives accept an analog ± 10 VDC Position feedback, typically in the form of a load-mounted potentiometer. The feedback signal must be conditioned so that the voltage does not exceed ± 10 V, and is connected to the drive through the Programmable Analog Input. In DriveWare, the connection method that is used must be selected under the Position Loop Feedback options. See the DriveWare Software Guide for more information.

2.6 Command Sources

The input command source for DZMANTU drives can be provided by one of the following options.

2.6.1 Embedded Click&Move® Program

DZMANTU drives are designed to store and run an embedded Click&Move® program. The Click&Move development software is used to create motion code and PLC logic. The code is compiled for the targeted drive platform and then downloaded to the drive via DriveWare. I/O is local to the drive.

2.6.2 $\pm 10\text{V}$ Analog


DZMANTU drives accept a differential or single-ended analog signal with a range of $\pm 10\text{ V}$ from an external source. The input command signals should be connected to pins P1-3 and P1-5. See [“Programmable Analog Input” on page 43](#) for more information.

2.6.3 Encoder Following

DZMANTU drives can utilize Encoder Following as a form of input command. In Encoder Following mode, an auxiliary differential encoder signal can be used to command the drive in a master/slave configuration. The gearing ratio (input counts to output counts ratio) can be configured in DriveWare by the user. Encoder Following is only a valid option when the drive is operated in position mode. The auxiliary encoder signal input should be connected to the AUX ENC pins. See [“Auxiliary Encoder” on page 33](#) for more information.

2.7 Pinouts and Pin Layouts

2.7.1 DZMANTU



P2 - Power Connector	
Pin	Description
SAFE1	STO OUT RETURN
SAFE2	STO OUTPUT
SAFE3	STO-2 RETURN
SAFE4	STO-2
SAFE5	STO-1 RETURN
SAFE6	STO-1
SAFE7	NC
SAFE8	NC
1	AUX SUPPLY INPUT
2	
3-10	HIGH VOLTAGE
11	NC
12	
13-20	GROUND
21	NC
22	
23-30	MOTOR A
31	NC
32	
33-40	MOTOR B
41	NC
42	
43-50	MOTOR C

P1 - Signal Connector DZPANTU			
Pin	Description	Pin	Description
1	RESERVED	2	RESERVED
3	PAI-1-	4	ADDR1
5	PAI-1+	6	ADDR0
7	GROUND	8	GROUND
9	MOT ENC B- / COS-	10	MOT ENC A- / SIN-
11	MOT ENC B+ / COS+	12	MOT ENC A+ / SIN+
13	GROUND	14	+5V OUT
15	MOTOR THERMISTOR	16	GROUND
17	MOT ENC CLK-	18	MOT ENC DATA-
19	MOT ENC CLK+	20	MOT ENC DATA+
21	MOT ENC I-	22	AUX ENC B-
23	MOT ENC I+	24	AUX ENC B+
25	AUX ENC I-	26	AUX ENC A-
27	AUX ENC I+	28	AUX ENC A+
29	+5V OUT	30	HALL B
31	HALL C	32	HALL A
33	HS PDI-5-	34	HS PDI-4-
35	HS PDI-5+	36	HS PDI-4+
37	GP PDO-5	38	GP PDI-3
39	GP PDO-4	40	GP PDI-2
41	GP PDO-3	42	GP PDI-1
43	GP PDO-2	44	AMP STATUS LED-
45	GP PDO-1	46	AMP STATUS LED+
47	RESERVED	48	RESERVED
49	+5V USB OUT	50	DATA- USB
51	GND USB	52	DATA+ USB
53	GROUND	54	GROUND
55	RESERVED	56	RESERVED
57	RESERVED	58	RESERVED
59	GROUND	60	RESERVED
61	RESERVED	62	RESERVED
63	RESERVED	64	RESERVED
65	RESERVED	66	RESERVED
67	GROUND	68	GROUND
69	RESERVED	70	RESERVED
71	RESERVED	72	RESERVED
73	RESERVED	74	RESERVED
75	RESERVED	76	RESERVED
77	RESERVED	78	RESERVED
79	GROUND	80	GROUND
81	TX- OUT	82	RX- OUT
83	TX+ OUT	84	RX+ OUT
85	+3V OUT	86	+3V OUT
87	TX- IN	88	RX- IN
89	TX+ IN	90	RX+ IN
91	GROUND	92	GROUND
93	RESERVED	94	LINK / ACT OUT
95	RESERVED	96	LINK / ACT IN

2.8 System Requirements

To successfully incorporate a DZMANTU servo drive into your system, you must be sure it will operate properly based on electrical, mechanical, and environmental specifications while anticipating impacts on performance.

2.8.1 Specifications Check

Before selecting a DZMANTU servo drive, a user should consider the requirements of their system. This involves calculating the voltage, current, torque, and power requirements of the system, as well as considering the operating environment and any other equipment the drive will be interfacing with. Before attempting to install or operate a DZMANTU servo drive, be sure all the following items are available:

- DZMANTU Servo Drive
- DZMANTU Servo Drive Datasheet (specific to your model)
- DZMANTU Series Digital Hardware Installation Manual
- DriveWare Software Guide



Note

DZMANTU servo drives are shipped with no other connectors or mounting components other than the signal and power header pins on the drive PCB itself. However, mounting cards and mating connectors are readily available. See ["Mounting Card" on page 25](#) for the *ADVANCED* Motion Controls DZMANTU mounting card and mating connector kit. Customized mounting options are also available for orders with sufficient volume.

2.8.2 Motor Specifications

DZMANTU digital servo drives have a given current and voltage rating unique to each drive. Based on the necessary application requirements and the information from the datasheet of the motor being used, a drive may be selected that will best suit the motor capabilities. Some general guidelines that are useful when pairing a servo drive with a motor:

- The **motor current** I_M is the required motor current in amps DC, and is related to the torque needed to move the load by the following equation:

$$I_M = \frac{\text{Torque}}{K_T}$$

Where:

K_T -motor torque constant

The motor current will need to be calculated for both continuous and peak operation. The peak torque will be during the acceleration portion of the move profile. The continuous torque is the average torque required by the system during the move profile, including dwell times.

- The system voltage requirement is based on the motor properties and how fast and hard the motor is driven. The system voltage requirement is equal to the **motor voltage, V_M** , required to achieve the move profile.

$$V_M = (K_E \cdot S_M) + (I_M \cdot R_M)$$

Where:

- K_E -motor back EMF constant
- S_M -motor speed (use the maximum speed expected for the application)
- I_M -motor current (use the maximum current expected for the application)
- R_M -motor line-to-line resistance

- The motor inductance is vital to the operation of servo drives, as it ensures that the DC motor current is properly filtered.



Caution

A motor that does not meet the rated minimum inductance value of the DZMANTU drive may damage the drive! If the motor inductance value is less than the minimum required for the selected drive, use of an external filter card is necessary.

A minimum motor inductance rating can be found on the drive datasheet. If the drive is operated below the maximum rated voltage, the minimum load inductance requirement may be reduced.


2.8.3 Power Supply Specifications

DZMANTU servo drives operate off an isolated unregulated DC Power Supply (see [Table 2.1](#) for drive model power supply ranges and over-voltage shutdown values). To avoid nuisance over- or under-voltage errors caused by fluctuations in the power supply, the system power supply voltage should be at least 10% above the entire system voltage requirement, and at least 10% below the lowest value of the following:

- Drive over voltage
- External shunt regulator turn-on voltage

Use of a shunt regulator is necessary in systems where motor deceleration or a downward motion of the motor load will cause the system's mechanical energy to be regenerated via the drive back onto the power supply. This regenerated energy can charge the power supply capacitors to levels above that of the drive over-voltage shutdown level. If the power supply capacitance is unable to handle this excess energy, or if it is impractical to supply enough capacitance, then an external shunt regulator must be used to dissipate the regenerated energy. The shunt regulator will "turn-on" at a certain voltage level (set below the drive over-voltage shutdown level) and discharge the regenerated electric energy in the form of heat.

The diagram below provides a possible example of an appropriate system power supply voltage for a DZMANTU-020B080 drive using an external shunt regulator.

FIGURE 2.4 Sample DZMANTU-020B080 Power Supply Selection

The power supply current rating is based on the maximum current that will be required by the system. If the power supply powers more than one drive, then the current requirements for each drive should be added together. Due to the nature of servo drives, the current into the drive does not always equal the current out of the drive. However, the *power* in is equal to the *power* out. Use the following equation to calculate the **power supply output current, I_{PS}** , based on the motor current requirements.

$$I_{PS} = \frac{V_M \cdot I_M}{V_{PS} \cdot (0.98)}$$

Where:

- V_{PS} -nominal power supply voltage
- I_M -motor current
- V_M -motor voltage

Use values of V and I at the point of maximum power in the move profile (when $V_M I_M = \max$). This will usually be at the end of a hard acceleration when both the torque and speed of the motor is high.


2.8.4 Environment

To ensure proper operation of a DZMANTU servo drive, it is important to evaluate the operating environment prior to installing the drive.

TABLE 2.3 Environmental Specifications

Parameter	Description
Ambient Temperature Range	See Figure 2.5
Baseplate Temperature Range	0 - 75 °C
Humidity	90%, non-condensing
Altitude	0-4000m

Ambient Temperature Range and Thermal Data DZMANTU drives contain a built-in over-temperature disabling feature if the baseplate temperature rises above the maximum baseplate temperature value, specified in [Table 2.3](#). For a specific DC supply voltage and a specific output current, [Figure 2.5](#) below specifies an upper limit to the ambient temperature range DZMANTU drives can operate within while keeping the baseplate temperature below the maximum baseplate temperature. It is recommended to mount the baseplate of the drive to a heatsink for best thermal management results.

FIGURE 2.5 DZMANTU Drives Maximum Ambient Temperature Range

1. The heatsink used in the above tests is 15" x 22" x 0.65" aluminum plate.

Shock/Vibrations While DZMANTU drives are designed to withstand a high degree of mechanical shock and vibration, too much physical abuse can cause erratic behavior, or cause the drive to cease operation entirely. Be sure the drive is securely mounted in the system to reduce the shock and vibration the drive will be exposed to. The best way to secure the drive against mechanical vibration is to use screws to mount the DZMANTU drive against its baseplate. For information on mounting options and procedures, see [“Mounting” on page 25](#).



Caution

Care should be taken to ensure the drive is securely mounted in a location where no moving parts will come in contact with the drive.

3 Integration in the Servo System

This chapter will give various details on incorporating a DZMANTU servo drive into a system, such as how to design the PCB traces on an interface board, how to properly the drive, and how to properly connect motor wires, power supply wires, feedback wires, communication cables, and inputs into the servo drive.

3.1 LVD Requirements

The servo drives covered in the LVD Reference report were investigated as components intended to be installed in complete systems that meet the requirements of the Machinery Directive. In order for these units to be acceptable in the end users' equipment, the following conditions of acceptability must be met.

1. European approved overload and current protection must be provided for the motors as specified in section 7.2 and 7.3 of EN60204.1.
2. A disconnect switch shall be installed in the final system as specified in section 5.3 of EN60204.1.
3. All drives that do not have a grounding terminal must be installed in, and conductively connected to a grounded end use enclosure in order to comply with the accessibility requirements of section 6, and to establish grounding continuity for the system in accordance with section 8 of EN60204.1.
4. A disconnecting device that will prevent the unexpected start-up of a machine shall be provided if the machine could cause injury to persons. This device shall prevent the automatic restarting of the machine after any failure condition shuts the machine down.
5. European approved over current protective devices must be installed in line before the servo drive, these devices shall be installed and rated in accordance with the installation instructions (the installation instructions shall specify an over current rating value as low as possible, but taking into consideration inrush currents, etc.). Servo drives that incorporate their own primary fuses do not need to incorporate over protection in the end users' equipment.

These items should be included in your declaration of incorporation as well as the name and address of your company, description of the equipment, a statement that the servo drives must not be put into service until the machinery into which they are incorporated has been declared in conformity with the provisions of the Machinery Directive, and identification of the person signing.

3.2 CE-EMC Wiring Requirements

The following sections contain installation instructions necessary for meeting EMC requirements.

Contact the factory for assistance in determining the type of drive in use.

General

1. Shielded cables must be used for all interconnect cables to the drive and the shield of the cable must be grounded at the closest ground point with the least amount of resistance.
2. The drive's metal enclosure must be grounded to the closest ground point with the least amount of resistance.
3. The drive must be mounted in such a manner that the connectors and exposed printed circuit board are not accessible to be touched by personnel when the product is in operation. If this is unavoidable there must be clear instructions that the amplifier is not to be touched during operation. This is to avoid possible malfunction due to electrostatic discharge from personnel.

Analog Input Drives

4. A Fair Rite model 0443167251 round suppression core must be fitted to the low level signal interconnect cables to prevent pickup from external RF fields.

PWM Input Drives

5. A Fair Rite model 0443167251 round suppression core must be fitted to the PWM input cable to reduce electromagnetic emissions.

MOSFET Switching Drives

6. A Fair Rite model 0443167251 round suppression core must be fitted at the load cable connector to reduce electromagnetic emissions.
7. An appropriately rated Cosel TAC series AC power filter in combination with a Fair Rite model 5977002701 torroid (placed on the supply end of the filter) must be fitted to the AC supply to any MOSFET drive system in order to reduce conducted emissions fed back into the supply network.

IGBT Switching Drives

8. An appropriately rated Cosel TAC series AC power filter in combination with a Fair Rite model 0443167251 round suppression core (placed on the supply end of the filter) must be fitted to the AC supply to any IGBT drive system in order to reduce conducted emissions fed back into the supply network.
9. A Fair Rite model 0443164151 round suppression core and model 5977003801 torroid must be fitted at the load cable connector to reduce electromagnetic emissions.

Fitting of AC Power Filters

10. It is possible for noise generated by the machine to "leak" onto the main AC power, and then get distributed to nearby equipment. If this equipment is sensitive, it may be

adversely affected by the noise. AC power filters can filter this noise and keep it from getting on the AC power signal. The above mentioned AC power filters should be mounted flat against the enclosure of the product using the mounting lugs provided on the filter. Paint should be removed from the enclosure where the filter is fitted to ensure good metal to metal contact. The filter should be mounted as close to the point where the AC power filter enters the enclosure as possible. Also, the AC power cable on the load end of the filter should be routed far from the AC power cable on the supply end of the filter and all other cables and circuitry to minimize RF coupling.

3.2.1 Ferrite Suppression Core Set-up

If PWM switching noise couples onto the feedback signals or onto the signal ground, then a ferrite suppression core can be used to attenuate the noise. Take the motor leads and wrap them around the suppression core as many times as reasonably possible, usually 2-5 times. Make sure to strip back the cable shield and only wrap the motor wires. There will be two wires for single phase (brushed) motors and 3 wires for three phase (brushless) motors. Wrap the motor wires together as a group around the suppression core and leave the motor case ground wire out of the loop. The suppression core should be located as near to the drive as possible. TDK ZCAT series snap-on filters are recommended for reducing radiated emissions on all I/O cables.

3.2.2 Inductive Filter Cards


Inductive filter cards are added in series with the motor and are used to increase the load inductance in order to meet the minimum load inductance requirement of the drive. They also serve to counteract the effects of line capacitance found in long cable runs and in high voltage systems. These filter cards also have the added benefit of reducing the amount of PWM noise that couples onto the signal lines.

3.3 Grounding

In most servo systems all the case grounds should be connected to a single Protective Earth (PE) ground point in a "star" configuration. Grounding the case grounds at a central PE ground point through a single low resistance wire for each case ground reduces the chance for ground loops and helps to minimize high frequency voltage differentials between components. All ground wires must be of a heavy gauge and be as short as possible. The following should be securely grounded at the central PE grounding point:

- Motor chassis
- Controller chassis
- Power supply chassis
- PCB Interface chassis

FIGURE 3.1 System Grounding



Ground cable shield wires at the mounting card or PCB interface side to a chassis earth ground point. The DC power ground and the input reference command signal ground are oftentimes at a different potential than chassis/PE ground. The signal ground of the controller must be connected to the signal ground of the DZMANTU drive to avoid picking up noise due to the "floating" differential servo drive input. On all DZMANTU drives, the DC power ground and the input command signal ground are referenced to each other internally. In systems using an isolated DC power supply, signal ground and/or power ground can be referenced to chassis ground. First decide if this is both appropriate and safe. If this is the case, they can be grounded at the central grounding point.



Grounding is important for safety. The grounding recommendations in this manual may not be appropriate for all applications and system machinery. It is the responsibility of the system designer to follow applicable regulations and guidelines as they apply to the specific servo system.

3.4 Wiring

Servo system wiring typically involves wiring a controller (digital or analog), a servo drive, a power supply, and a motor. Wiring these servo system components is fairly easy when a few simple rules are observed. As with any high efficiency PWM servo drive, the possibility of noise and interference coupling through the cabling and wires can be harmful to overall system performance. Noise in the form of interfering signals can be coupled:

- Capacitively (electrostatic coupling) onto signal wires in the circuit (the effect is more serious for high impedance points).
- Magnetically to closed loops in the signal circuit (independent of impedance levels).
- Electromagnetically to signal wires acting as small antennas for electromagnetic radiation.
- From one part of the circuit to other parts through voltage drops on ground lines.

Experience shows that the main source of noise is the high DV/DT (typically about 1V/nanosecond) of the drive's output power stage. This PWM output can couple back to the signal lines through the output and input wires. The best methods to reduce this effect are to move signal and motor leads apart, add shielding, and use differential inputs at the drive. For extreme cases, use of an inductive filter card or a noise suppression device is recommended. Unfortunately, low-frequency magnetic fields are not significantly reduced by metal enclosures. Typical sources are 50 or 60 Hz power transformers and low frequency current changes in the motor leads. Avoid large loop areas in signal, power-supply, and motor wires. Twisted pairs of wires are quite effective in reducing magnetic pick-up because the enclosed area is small, and the signals induced in successive twists cancel.

3.4.1 Wire Gauge

As the wire diameter decreases, the impedance increases. Higher impedance wire will broadcast more noise than lower impedance wire. Therefore, when selecting the wire gauge for the motor power wires, power supply wires, and ground wires, it is better to err on the side of larger diameter wire rather than too thin. This recommendation becomes more critical as the cable length increases.

3.4.2 Motor Wires

The motor power wires supply power from the drive to the motor. Use a twisted, shielded pair for the motor power cables to reduce the amount of noise coupling to sensitive components.

- For a single phase motor or voice coil, twist the two motor wires together as a group.
- For a three phase motor, twist all three motor wires together as a group.

Ground the motor power cable shield at one end only to the mounting card or PCB interface chassis ground. The motor power leads should be bundled and shielded in their own cable and kept separate from feedback signal wires.

DO NOT use wire shield to carry motor current or power!



3.4.3 Power Supply Wires


The PWM current spikes generated by the power output-stage are supplied by the internal power supply capacitors. In order to keep the current ripple on these capacitors to an acceptable level it is necessary to use heavy power supply leads and keep them as short as possible. Reduce the inductance of the power leads by twisting them. Ground the power supply cable shield at one end only to the mounting card or PCB interface chassis ground.

When multiple drives are installed in a single application, precaution regarding ground loops must be taken. Whenever there are two or more possible current paths to a ground connection, damage can occur or noise can be introduced in the system. The following rules apply to all multiple axis installations, regardless of the number of power supplies used:

1. Run separate power supply leads to each drive directly from the power supply filter capacitor.
2. Never "daisy-chain" any power or DC common connections. Use a "star"-connection instead.

3.4.4 Feedback Wires

Use of a twisted, shielded pair for the feedback wires is recommended. Ground the shield at one end only to the mounting card or PCB interface chassis ground. Route cables and/or wires to minimize their length and exposure to noise sources. The motor power wires are a major source of noise, and the motor feedback wires are susceptible to receiving noise. This is why it is never a good idea to route the motor power wires with the motor feedback wires, even if they are shielded. Although both of these cables originate at the drive and terminate at the motor, try to find separate paths that maintain distance between the two. A rule of thumb for the minimum distance between these wires is 10cm for every 10m of cable length.



3.4.5 Input Reference Wires

Use of a twisted, shielded pair for the input reference wires is recommended. Connect the reference source "+" to "+REF IN", and the reference source "-" (or common) to "-REF IN". Connect the shield to the mounting card or PCB interface chassis ground. The servo drive's reference input circuit will attenuate the common mode voltage between signal source and drive power grounds.



Notice

In case of a single-ended reference signal, connect the command signal to "+ REF IN" and connect the command return and "- REF IN" to signal ground.

Long signal wires (10-15 feet and up) can also be a source of noise when driven from a typical OP-AMP output. Due to the inductance and capacitance of the wire the OP-AMP can oscillate. It is always recommended to set a fixed voltage at the controller and then check the signal at the drive with an oscilloscope to make sure that the signal is noise free.

3.4.6 Communication Wires

It is recommended to use industry-standard CAT 5e or CAT 6 ethernet cables together with dual RJ-45 connectors for Ethernet network connections. Typical RJ-45 connectors will feature LEDs for Ethernet network monitoring (link verification, network activity, status, and error functions). DZMANTU drives include LED output signals for this purpose. See ["Ethernet Interface" on page 38](#) for the recommended interface connections.

3.5 Mounting

This section provides instructions and information on the different ways to mount a DZMANTU servo drive to a PCB.


3.5.1 Mounting Card

DZMANTU servo drives are designed to interface directly with the *ADVANCED* Motion Controls’ mounting card MC1XDZPE01. The mounting card is designed both for initial design and prototyping purposes, and for implementation into the final system design as well. It is highly recommended to use the MC1XDZPE01 mounting card, as the proven communication and networking capabilities will streamline and simplify the design and testing process.

TABLE 3.1 DZPANTU Mounting Card

Mounting Card Part Number	Description
MC1XDZPE01	Single Axis Ethernet Mounting Card


FIGURE 3.3 MC1XDZPE01 Mounting Card (shown card only and card with drive mounted)



Pinouts, dimensions, and ordering information for the MC1XDZPE01 are obtainable on the mounting card datasheet, available for download at www.a-m-c.com. The datasheet includes information on mounting card mating connectors and configuration options. In addition, users may design their own mounting card to mate with a DZMANTU servo drive. For more information on designing a compatible PCB interface card, see “PCB Design” on page 27 and “Interface Circuitry Examples” on page 29.

MC1XDZPE01 Mounting Standoffs The MC1XDZPE01 is shipped with two standoff spacers used to secure the mounting card to the drive baseplate. Standoff spacers should be mounted between the MC1XDZPE01 chassis mounting holes and the drive baseplate mounting holes, as shown in Figure 3.4.

FIGURE 3.4 MC1XDZPE01 Mounting Card with standoff spacers



Mating Connector Kit Mating connector housing and crimp pins for DZMANTU mounting cards can be ordered as a kit using part number **KC-MC1XDZP01**. This includes mating connector housing and crimp style contacts for the I/O, Feedback, and Auxiliary Feedback connectors. The recommended tool for crimping the contacts is Molex part number **63811-6300**.

TABLE 3.2 DZMANTU Mounting Card and Mating Connector Kits

Mounting Card Part Number	Associated Mating Connector Kit
MC1XDZPE01	KC-MC1XDZP01

TABLE 3.3 Mating Connector Kit KC-MC1XDZP01 Included Connectors

Description	Qty. Included	Manufacturer and Part Number
20-port, dual-row, 2.00 mm spaced plug	1	Molex: P/N 51353-2000 (housing); 56134-9100 (contacts)
18-port, dual-row, 2.00 mm spaced plug	1	Molex: P/N 51353-1800 (housing); 56134-9100 (contacts)
10-port, dual-row, 2.00 mm spaced plug	1	Molex: P/N 51353-1000 (housing); 56134-9100 (contacts)
8-port, dual-row, 2.00 mm spaced plug	1	Molex: P/N 51353-0800 (housing); 56134-9100 (contacts)

3.6 PCB Design

Before designing a PCB interface for DZMANTU drives, it is highly recommended to use one of the mounting cards listed in [“Mounting Card” on page 25](#) during the testing and prototyping stages of a system’s design. The proven networking and communication capabilities of the mounting card models will minimize troubleshooting and streamline the testing and integration process. For certain systems and applications, the mounting cards can also be designed into the end-product.

For systems with spacing restrictions or other limiting factors that require a PCB interface, there are some key features that must be kept in mind to ensure proper operation.

3.6.1 Trace Width and Routing

The proper design and implementation of the PCB traces on an interface card is essential in maximizing drive efficiency and noise reduction.

- Keep high and low power signals separated - Although DZMANTU servo drives have an internal connection between power and signal ground, the traces emitting from the Power Connector carry high currents and voltages, while the traces emitting from the Signal Connector carry low currents and voltages. Refrain from routing power traces near signal traces, and never route them in parallel. If power traces and signal traces need to cross, they should do so at right angles.
- Keep high current traces short - Traces carrying high current, such as the DC Power traces and Motor Power traces, should be kept short and close together to minimize noise emissions. Also, keep DC Power traces separate from Motor Power traces where possible.
- Design for maximum values - Adjacent traces can carry a voltage potential equal to the maximum DC power supply value, and carry current of both the servo drive’s peak and continuous current ratings. The trace width and copper plating thickness will need to take these maximum values into account. Also, be aware that DZMANTU servo drive pin headers have a maximum current rating of 3 amps DC per pin. In order to achieve a higher overall peak current capability, some high current signals “share” a group of pins to spread the current between them. High current traces running to these pin groups should be inter-connected on the PCB board. Consult the drive’s datasheet or the “Pinouts” section in [“Products Covered” on page 5](#) for these pin groupings.

3.6.2 PCB Mounting Options

DZMANTU servo drives can be directly integrated onto a PCB, either by mounting the board on socket connectors or by actually soldering the drive to the board.


Mating Connectors DZMANTU drives use square post male headers that are designed for fast and easy removal from PCB-mount socket connectors, making this option particularly useful when prototyping. The socket mating connectors compatible with DZMANTU drives are shown in the table below.

TABLE 3.4 Socket Mating Connectors

Connector	Pins	Pin Size	Manufacturer and Part Number
P1 Signal Connector	96	0.41mm square post	Samtec: CLP-148-02-F-D-BE-A-K (bottom entry) FLE-148-01-G-DV-A-K (top entry)
P2 Power Connector	58	0.51mm square post	Samtec: CLT-129-02-F-D-BE-A-K (bottom entry) TLE-129-01-G-DV-A-K (top entry)

Soldering Soldering a DZMANTU drive directly to a PCB provides added support against mechanical shocks and vibration. It is recommended to solder drives to a PCB following the industry standard for Acceptability of Electronic Assemblies IPC-A-610D. Use solder with no-clean flux. DZMANTU drives can be soldered by any of the following methods:

- wave soldering
- hand soldering
- selective wave soldering

FIGURE 3.5 DZMANTU PCB Footprint

To clean the PCB and drive after soldering, it is recommended to gently apply isopropyl alcohol or a cleaning agent with a soft-bristled brush. Use care not to apply downward pressure, but rather lightly brush the PCB and drive. Do not immerse the drive in a cleaning agent.

Screw Mounting For added stability and support, DZMANTU drives can be mounted with screws in tandem with one of the options above. DZMANTU drives use mounting screws to maintain mechanical stability between the baseplate and drive PCB. These drive mounting screw holes can also be used to secure the drive to a mounting card or external PCB interface. See [“Physical Dimensions” on page 48](#) and/or the specific drive’s datasheet for exact screw locations and dimensions.

DZMANTU drives can also be screw mounted through the mounting screw holes on either side of the drive baseplate onto an external heatsink or other mounting plate for added stability and resiliency against mechanical vibration. Mounting to an external heatsink also provides better thermal management behavior than other mounting options. See [“Ambient Temperature Range and Thermal Data” on page 16](#) for more info.

3.6.3 Interface Circuitry Examples


The following sections show examples of how portions of an interface board could be designed to work with a DZMANTU servo drive, and also contain general connection rules and instructions.



Figures are intended for reference only; review all circuitry for compatibility and compliance with the intended system application and design. Appropriate datasheets and/or installation manuals for external hardware (RJ-45 connectors, USB connector, feedback devices, etc.) should be carefully reviewed for specific requirements/circuitry before designing any interface PCB.

Address Line Inputs The two address line inputs on DZMANTU drives are sensitive to voltage level. Voltages slightly above 3V can lead to damage of the drive. The user's interface card must be designed to take this into consideration, and ensure voltages greater than 3V are not applied to the address lines. The address lines should not be left floating. They should either have a voltage applied to them or be grounded (grounding both address lines will utilize the default address that is stored in non-volatile memory).


FIGURE 3.6 Recommended Address Line Input



Be sure not to apply voltages greater than 3V to the address lines to prevent damage to the drive! Example voltage levels are given in ["Ethernet Node Address Selector" on page 43](#) and on the drive's datasheet.


Digital Inputs (Standard) DZMANTU drives provide 3 single-ended TTL level programmable digital inputs. [Figure 3.7](#) below is an example of how the mounting card/interface PCB should be designed for proper operation.

FIGURE 3.7 Recommended Standard Digital Inputs Interface



Digital Inputs (High Speed) DZMANTU drives provide 2 high speed differential programmable digital inputs. These inputs can be used for Capture, Step and Direction, PWM and Direction, or Auxiliary Encoder inputs. Figure 3.8 below is an example of how the mounting card/interface board should be designed for proper operation.


FIGURE 3.8 Recommended High Speed Digital Inputs Interface



*R only used with single-ended inputs (1kohm recommended)


Digital Outputs DZMANTU drives provide 5 single-ended programmable digital outputs. Figure 3.9 is an example of how the mounting card/interface PCB should be designed for proper operation.

FIGURE 3.9 Recommended Digital Outputs Interface




Analog Inputs DZMANTU drives provide 1 programmable analog input. Figure 3.10 below is an example of how the mounting card/interface PCB should be designed for proper operation. For single-ended use, PAI-1- should be shorted to signal ground.

FIGURE 3.10 Recommended Analog Inputs Interface




Hall Sensor Inputs DZMANTU drives allow single-ended Hall Sensor inputs both for commutation and velocity feedback. For single-ended Halls, no additional circuitry is required on the PCB interface. For differential Halls, the inputs must first go through a signal conditioning amplifier. Users designing their own mounting card or interface PCB must be sure to include this feature in their design. [Figure 3.11](#) shows the recommended single-ended Hall Sensor inputs, as well as the signal conditioning circuitry that is required for differential inputs.

FIGURE 3.11 Recommended Hall Sensor Interface




For BiSS C-Mode encoders, only the Data and Clock inputs are used. The Sine, Cosine, and Index pins can be left open. [Figure 3.12](#) shows the recommended circuitry.

If single-ended incremental encoder inputs are to be used, the negative encoder input pin should be biased as shown in [Figure 3.12](#), and the encoder input should connect to the positive encoder input pin.



Auxiliary Encoder DZMANTU drives accept a differential auxiliary encoder input that can be used for auxiliary position feedback, or as a command source when the drive is configured for Encoder Following. The auxiliary encoder signals are connected through the AUX ENC pins (P1-22/24, 25/27, and 26/28). Hardware settings and options for the auxiliary encoder can be entered and configured in DriveWare. The drive will have to be operating in Position Mode in order to utilize the auxiliary encoder input. If appropriate, the encoder can be powered by the +5V Supply Output pin provided on the DZMANTU drive. Check the motor and encoder specifications for the encoder voltage and current requirements. Figure 3.13 shows the recommended circuitry.

FIGURE 3.13 Auxiliary Encoder Input Connections




Logic Supply Input DZMANTU drives allow the option of connecting an external logic power supply. This logic power should be referenced to the drive signal ground (internally tied to power ground). [Figure 3.14](#) shows how to connect a Logic Power Supply through a mounting card/interface PCB. If no external logic supply is connected, the logic power will be generated internally from the main DC power.




When using a separate logic power supply, the logic power must be turned on before the main power supply.

FIGURE 3.14 Recommended Auxiliary Logic Supply Input




DC Power Input [Figure 3.15](#) shows how a DZMANTU servo drive connects to an isolated DC Power Supply through a mounting card/interface PCB. Notice that the power supply wires are shielded, and that the power supply case is grounded at the single point system ground (PE Ground). The cable shield should be grounded at the mounting card or PCB interface side to chassis ground.

FIGURE 3.15 Recommended DC Power Input



Motor Power Output The figures below shows how a DZMANTU servo drive connects to various motor types through a mounting card/interface PCB. Notice that the motor wires are shielded, and that the motor housing is grounded to the single point system ground (PE Ground). The cable shield should be grounded at the mounting card or PCB interface side to chassis ground.

FIGURE 3.16 Recommended Motor Power Output



Caution

If using relays or other means to disconnect the motor leads, be sure the drive is disabled before reconnecting the motor leads to the drive. Connecting the motor leads to the drive while it is enabled can generate extremely high voltage spikes which will damage the drive.



Caution

For applications using stepper motors, the maximum motor speed will be limited (typically ~600 RPM max).

STO (Safe Torque Off) Interface Some models of the DZMANTU drive family feature an external dedicated +5VDC STO safety function designed to monitor an external 5V STO input from the user system and disable the motor output during an STO event. The STO circuit uses +5VDC sinking single-ended isolated inputs for STO functionality. Both STO1 and STO2 must be active (HIGH) to allow torque output at the drive motor outputs.

TABLE 3.5 STO Signal Behavior


STO 1	STO 2	Motor Outputs	STO OUT
Active (HIGH)	Active (HIGH)	Enabled	Open
Active (HIGH)	Not Active (LOW)	Disabled	Closed
Not Active (LOW)	Active (HIGH)	Disabled	Closed
Not Active (LOW)	Not Active (LOW)	Disabled	Closed

The STO circuitry also features an STO status output (STO OUT) that signifies when an STO condition has occurred. This status is also viewable in the setup software as an indicator only. The STO OUT output functions as a switch. When an STO event occurs, the STO OUT switch becomes CLOSED. When the drive is in normal functional operation (STO 1 and STO 2 = 5V) the STO OUT switch is OPEN.

FIGURE 3.17 STO Connections

See “Mounting” on page 25 and “PCB Design” on page 27 for connector and mating hardware information, and “Pinouts and Pin Layouts” on page 13 for pin numbering information. Functional Safety is TÜV Rheinland certified and meets requirements of the following standards:

- EN ISO 13849-1 -- Category 4 / PL e
- EN IEC 61800-5-2 -- STO (SIL 3)
- EN 62061 -- SIL CL3
- IEC 61508 -- SIL 3



The user must verify proper operation of the monitoring circuit (STO 1 and STO 2) at least once per month to maintain SIL 3, Cat 4 / PL e certification. The monitoring circuit is required to be examined by an external logic element when STO is incorporated into a complete drive system in order for proper diagnostics to be fully implemented and utilized in the FMEA calculation (see “STO Operation Test” on page 37). The calculation of the safety relevant parameters are based on a proof test interval of one year and have shown that the requirements of up to SIL 3 are fulfilled. The safety relevant parameters are:

- Safe-Failure-Fraction: SFF = 97%
- Probability of a dangerous failure per hour: PFH = 1.3×10^{-8} 1/h
- Average probability of a dangerous failure on demand (1 year): $PFD_{avg} = 1.7 \times 10^{-5}$



Note

The above assessment and safety values defined were assessed with the STO function incorporated into the DigiFlex Performance DZMANTU drive family. Product data for the DZMANTU drive family can be found by visiting www.a-m-c.com.

STO Operation Test

To maintain SIL 3, Cat 4 / PL e certification, the operation of the STO monitoring circuit (STO1 and STO2) must be verified at least once per month. The following procedure provides an example of a method to verify correct STO functionality. Note that it is the responsibility of the system operator to ensure all personal and machine safety requirements for the system are properly enforced during the proof test.

1. Power on the drive.
2. Verify the drive is in an Enabled state (by monitoring via a digital controller or network commands).
3. Remove the voltage signal from the STO1 input pin via a digital controller signal, network command.
4. Verify that the drive is in a Disabled state (via network commands and by verifying the STO OUT switch has closed).
5. Re-apply the voltage signal to the STO1 pin. Verify that the drive is once again in an Enabled state (by monitoring via a digital controller or network commands).
6. Repeat the above steps for the STO2 signal.



Note

End-product certification may require a different interval test schedule or test requirements. It is the responsibility of the end-user to determine the required test interval and requirements for certifications other than stated above.

Ethernet Interface The LINK/ACT pins serve as Ethernet network indicators. LINK/ACT IN and LINK/ACT OUT are used to drive the corresponding LINK IN and LINK OUT LEDs on a typical RJ-45 connector. It is recommended to refer to the datasheet/installation manual for the RJ-45 device(s) in use for the appropriate interface circuitry required for the specific user system design and devices. For a design using an RJ-45 connector with integrated magnetics and LEDs, [Figure 3.18](#) shows typical connection implementation. For a design using a discrete RJ-45 connector using external magnetics and LEDs, [Figure 3.19](#) shows typical connection implementation.

FIGURE 3.18 Recommended Ethernet Communication Interface (internal magnetics/LEDs)







FIGURE 3.19 Recommended Ethernet Communication Interface (external magnetics/LEDs)

USB Interface DZMANTU drives feature USB outputs that can be wired to a standard USB connection in either a single-axis configuration, or a multi-axis configuration through a USB hub controller. It is recommended to refer to www.usb.org and the datasheet/installation manual for the USB device(s) in use for the appropriate interface circuitry required for the specific system design and devices. Figure 3.20 shows typical USB connection guidelines.

FIGURE 3.20 Recommended USB Interface


Drive Status LEDs DZMANTU drives feature power bridge status LED outputs (AMP STATUS LED-, P1-44; AMP STATUS LED+, P1-46) that can be used with either a single Bi-Directional LED or two Uni-Directional LEDs. Figure 3.21 shows recommended wiring options and output states.

FIGURE 3.21 Recommended Drive Status LED Outputs



Motor Thermistor Input An external motor thermistor or thermal switch should be connected between the motor thermistor input (P1-15) and ground as shown in Figure 3.22.

FIGURE 3.22 Recommended Motor Thermistor Input



4 Operation and Features

This chapter will present a brief introduction on how to test and operate a DZMANTU servo drive. Read through this entire section before attempting to test the drive or make any connections.

4.1 Features and Getting Started

To begin operation with your DZMANTU drive, be sure to read and understand the previous chapters in this manual as well as the drive datasheet and the DriveWare Software Manual. Ensure that all system specifications and requirements have been met, and become familiar with the capabilities and functions of the drive. Also, be aware of the [“Troubleshooting”](#) section at the end of this manual for solutions to basic operation issues.

4.1.1 Initial Setup and Configuration

Carefully follow the grounding and wiring instructions in the previous chapters to make sure your system is safely and properly set up. For initial testing purposes, it is not necessary to use a controller to provide a command input, or to have any load attached to the motor. The items required will be:

- DZMANTU Servo Drive attached to Mounting Card or PCB Interface
- Motor
- DC Power Supply for supplying power to system
- DriveWare Setup Software and Software Manual for detailed instructions on how to setup, tune and configure a DZMANTU drive in DriveWare

The following steps outline the general procedure to follow when commissioning a DZMANTU drive for the first time. The DriveWare Software Manual contains more detailed information on each step.

1. **Check System Wiring:** Before beginning, check the wiring throughout the system to ensure proper connections and that all grounding and safety regulations have been followed appropriately for the system.



Caution

Do not apply power to the system until certain all wiring and grounding has been setup safely and properly!

When using a separate logic power supply, turn on the logic supply first before turning on the main power supply.

2. **Apply Power:** Power must be applied to the drive before any communication or configuration can take place. Turn on the Logic supply first for drives using a separate logic supply, then turn on the main Power supply. Use a multimeter or voltmeter to check that the power supply level is within the specified range.
3. **Establish Connection:** Open DriveWare on the PC. The DZMANTU drive should be attached to a mounting card or PCB interface, and connected to the PC with a USB cable. Choose the "Connect to a drive" option when DriveWare starts, and enter the appropriate communication settings in the options window that appears. See the DriveWare Software Guide for more information on connecting to a drive. For connection issues, see ["Connection Problems" on page 51](#).
4. **Input Motor Data:** Once DriveWare has connected to the drive, the motor and feedback information must be entered in DriveWare. This information is required for the drive to be configured properly.
5. **Set User Units:** User Units allows the user to set the general units that will be used in DriveWare. A variety of unit types are available, and DriveWare also offers the option of using custom units.
6. **Configure Drive Limits and Events:** DriveWare allows the user to manually configure system parameters and limits, and assign "actions" to specific events. The limits and their corresponding actions are used as both safety measures to avoid system damage, as well as parameter observation tools for drive configuration and troubleshooting.
7. **Tune the Current Loop:** Once the drive parameters are configured properly, the current loop must be tuned. This is the innermost loop and forms the basis of all motion. The current loop gains can be calculated based on the motor and application data entered in the previous two steps, or they can be set manually. The DriveWare Software Manual contains instructions on current loop tuning.
8. **Commute the Motor:** For Three Phase (Brushless) motors, commutation is necessary to maintain the optimal torque generation at any motor position. Typically this is accomplished by running the AutoCommutation routine in DriveWare. Also see ["Commutation" on page 44](#).

Once the drive has been commutated successfully, the drive is ready for further use, such as velocity or position loop tuning. Consult the DriveWare Software Manual for the correct procedure.

4.1.2 Input/Output Pin Functions

DZMANTU drives provide a number of various input and output pins for parameter observation and drive configuration options.

Ethernet Node Address Selector For DZMANTU drives, the address selector inputs are used to set the last octet of the IP Address of the drive within the Ethernet network. The value is set by applying a fixed voltage to the ADDR0 and ADDR1 pins (P1-6 and P1-4, respectively) to determine a hexadecimal node ID. ADDR0 sets the lower 4 bits of the address, and ADDR1 sets the upper 4 bits of the address. The values for ADDR0 and ADDR1 are always integer multiples of 1/5 V within the range of 0-3 V. Examples of the voltages required to set certain node ID's are given in [Table 4.1](#).

TABLE 4.1 Ethernet Address/Node ID Voltages

ADDR1		ADDR0		Node ID (Decimal)
Voltage	Value (Hex)	Voltage	Value (Hex)	
0	0	0	0	Address stored in NVM
0	0	0.2	1	001
0	0	0.4	2	002
...
3	F	2.6	D	253
3	F	2.8	E	254
3	F	3	F	255

Motor Thermistor Connect a 0-4 kohm thermistor between MOTOR THERMISTOR (P1-15) and GROUND. Thermistor behavior can be configured in DriveWare.

Programmable Digital Inputs DZMANTU drives provide three single-ended (P1-38,40,42) and five differential (P1-22/24, P1-25/27, P1-26/28, P1-33/35, and P1-34/36) Programmable Digital Inputs. These can be assigned to one or more functions in DriveWare.

Programmable Digital Outputs DZMANTU drives provide five single-ended General Purpose Programmable Digital Outputs on pins P1-37,39,41,43,45. These can be assigned to one or more functions in DriveWare.

Programmable Limit Switch (PLS) Outputs

When a digital output is configured as a Programmable Limit Switch through the setup software, the maximum frequency of the output will correspond to the table below.

TABLE 4.2 Maximum Digital Output Frequency for PLS Outputs

	Maximum Frequency
5V I/O Control Modules	5 kHz (for 20 kHz switching frequency) ¹

¹. Lower switching frequencies will result in lower output frequencies due to sampling on 5V I/O control modules.

Programmable Analog Input Pins P1-3 and P1-5 can be used as a differential Programmable Analog Input if they are not being used as an analog reference command input. A drive function can be assigned to the analog input in DriveWare.

4.1.3 Ethernet Communication LEDs Functionality

The LINK/ACT LEDs on a typical RJ-45 connector provide network status. [Table 4.3](#) below describes typical LED functionality.

TABLE 4.3 Network LEDs Function Protocol

LINK/ACT LED	
LED State	Description
Green - On	Valid Link - No Activity
Green - Flickering	Valid Link - Network Activity
Off	Invalid Link

4.1.4 Commutation

Motor commutation is the process that maintains an optimal angle between the magnetic field created by the permanent magnets in the motor and the electromagnetic field created by the currents running through the motor windings. This process ensures optimal torque or force generation at any motor position. Single phase (brushed) motors accomplish this process with internal commutators built into the motor housing. Three phase (brushless) motors require a correctly configured drive to commute properly, however. There are two ways to configure a DZ Plus drive to commute a three phase (brushless) motor in DriveWare:


- **AutoCommutation:** Most applications can use the AutoCommutation routine in DriveWare for configuring a drive to a specific motor. This routine will automatically detect the feedback devices attached to the motor and ask the user to verify them against the motor's data sheet.
- **Manual Commutation:** This process requires more time, and may not be as accurate as AutoCommutation. This method will have to be performed if:
 - The motor is mechanically restrained such that it is unable to rotate (AutoCommutation requires the motor to rotate 2 revolutions + 1 electrical cycle in both directions for a rotary motor, and 3 electrical cycles for a linear motor).
 - The motor or load has a significant amount of inertia.

For three phase (brushless) drives that use encoder feedback but no Hall Sensors, it is required to run the "Phase Detect" routine in DriveWare before AutoCommutation. Phase Detect works by sending a small current signal to the motor, prompting the motor to vibrate slightly for a few seconds. The encoder feedback from this movement provides a starting position for the motor, allowing the drive to then be properly commutated.

See the DriveWare Software Manual for more information on AutoCommutation, Manual Commutation, and Phase Detect.

DZMANTU servo drives allow either sinusoidal or trapezoidal commutation.


Sinusoidal Commutation Sinusoidal commutation provides greater performance and efficiency than trapezoidal commutation. DZMANTU drives can commute sinusoidally when connected to a motor-mounted encoder. Sinusoidal Commutation works by supplying current to each of the three motor phases smoothly in a sinusoidal pattern. The flow of current through each phase is shifted by 120 degrees. The sum of the current flowing through all three phases adds up to zero. [Figure 4.1](#) shows one electrical cycle of the motor phase currents.

FIGURE 4.1 Sinusoidal Commutation Motor Phase Currents

Trapezoidal Commutation Trapezoidal commutation is accomplished with the use of Hall Sensors on three phase (brushless) motors. DZMANTU drives can commute trapezoidally when used with properly spaced Hall Sensors. Unlike sinusoidal commutation, current flows through only two motor phases at a time with trapezoidal commutation. The Hall Sensors each generate a square wave with a certain phase difference (either 120- or 60-degrees) over one electrical cycle of the motor. This results in six distinct Hall states for each electrical cycle. Depending on the motor pole count, there may be more than one electrical cycle per motor revolution. The number of electrical cycles in one motor revolution is equal to the number of motor poles divided by 2. For example:

- a 6-pole motor contains 3 electrical cycles per motor revolution
- a 4-pole motor contains 2 electrical cycles per motor revolution
- a 2-pole motor contains 1 electrical cycle per motor revolution

The drive powers two of the three motor phases with DC current during each specific Hall Sensor state as shown in [Figure 4.2](#).

FIGURE 4.2 Hall Sensor Commutation and Motor Phase Current for 120-Degree Phasing

Note: DZM drives use a different commutation logic than other **ADVANCED** Motion Controls' servo drives. The diagrams provided here should be used only with DZM drives.

Table 4.4 shows the default commutation states for 120-degree and 60-degree phasing. Depending on the specific setup, the sequences may change after running AutoCommutation.

TABLE 4.4 Digital Drive Commutation Sequence Table

	60 Degree			120 Degree			Motor		
	Hall 1	Hall 2	Hall 3	Hall 1	Hall 2	Hall 3	Phase A	Phase B	Phase C
Valid	1	0	0	1	0	0	-	LOW	HIGH
	1	1	0	1	1	0	HIGH	LOW	-
	1	1	1	0	1	0	HIGH	-	LOW
	0	1	1	0	1	1	-	HIGH	LOW
	0	0	1	0	0	1	LOW	HIGH	-
	0	0	0	1	0	1	LOW	-	HIGH
Invalid	1	0	1	1	1	1	-	-	-
	0	1	0	0	0	0	-	-	-

4.1.5 Firmware

DZMANTU drives are shipped with the latest version of firmware already stored in the drive. Firmware updates are posted on *ADVANCED* Motion Controls' website, www.a-m-c.com. See the DriveWare Software Manual for information on how to check the drive's firmware version, and how to download new firmware into the drive when necessary.

A.1 Specifications Tables

TABLE A.1 Power Specifications

Description	Units	020B080	040B080	020B200
DC Supply Voltage Range	VDC	18-80		40-175
DC Bus Over Voltage Limit	VDC	89 (-5%)		193 (-3%)
DC Bus Under Voltage Limit	VDC	16 ($\pm 7.5\%$)		37 ($\pm 7.5\%$)
Logic Supply Voltage	VDC	18-80 (optional)		40-175 (optional)
Maximum Peak Output Current ¹	A (A_{rms})	20 (14.1)	40 (28.3)	20 (14.1)
Maximum Continuous Output Current	A (A_{rms})	10 (10)	20 (20)	10 (10)
Maximum Continuous Output Power	W	760	1520	1663
Maximum Power Dissipation at Continuous Current	W	40	80	88
Internal Bus Capacitance ²	μF	33	33	7
Minimum Load Inductance ³	μH	250		
Switching Frequency	kHz	20		
Maximum Output PWM Duty Cycle	%	85		

1. Capable of supplying drive rated peak current for 2 seconds with 10 second foldback to continuous value. Longer times are possible with lower current limits.

2. Additional 100 μF / 100V external bus capacitor required for 020B080 and 040B080 drive models, and 100 μF / 200V for 020B200 drive models.


3. Lower inductance is acceptable for bus voltages well below minimum. Use external inductance to meet requirements.

TABLE A.2 Control Specifications

Description	DZMANTU
Network Communication	Modbus TCP / Ethernet (USB for configuration)
Command Sources	Embedded Click&Move [®] , $\pm 10V$ Analog, Over the Network
Commutation Methods	Sinusoidal, Trapezoidal
Control Modes	Current, Velocity, Position
Motors Supported	Three Phase (Brushless Servo), Single Phase (Brushed Servo, Voice Coil, Inductive Load), Stepper (2- or 3-Phase Closed Loop), AC Induction (Closed Loop Vector)
Hardware Protection	40+ Configurable Functions, Over Current, Over Temperature (Drive & Motor), Over Voltage, Short Circuit (Phase-Phase & Phase-Ground), Under Voltage
Programmable Digital I/O	8 Inputs, 5 Outputs
Programmable Analog I/O	1 Input
Feedback Supported	Hall Sensors, Incremental Encoder, Aux. Incremental Encoder, 1Vp-p Sine/Cosine Encoder, Absolute Encoder (EnDat [®] 2.1, Hiperface [®] , or BiSS C-Mode), ± 10 VDC Position, Tachometer (± 10 VDC)

TABLE A.3 Environmental Specifications

Parameter	Description
Ambient Temperature Range	See Figure A.1
Baseplate Temperature Range	0 - 75 °C
Humidity	90%, non-condensing
Altitude	0-4000m

FIGURE A.1 DZEANTU Ambient Temperature Ranges

1. The heatsink used in the above tests is 15" x 22" x 0.65" aluminum plate.


TABLE A.4 Physical Dimensions

Description	Units	Value
Height	mm (in)	88.9 (3.5)
Length	mm (in)	63.5 (2.5)
Depth (not including pin lengths)	mm (in)	20.1 (0.8)
Weight	g (oz)	126.8 (4.47)
Baseplate Thickness	mm (in)	3.18 (0.13)

A.2 Mounting Dimensions

Mounting drawings in various 2D and 3D electronic CAD formats are available upon request. Contact *ADVANCED* Motion Controls for more information.

FIGURE A.2 DZMANTU Mounting Dimensions ([mm] inches)



This section discusses how to ensure optimum performance and, if necessary, get assistance from the factory.

B.1 Fault Conditions and Symptoms

An inoperative drive is typically an indication of a disabling fault condition. The fault condition can either be caused by a system parameter in excess of software or hardware limits, or by an event that has been user-configured to disable the drive upon occurrence.

To determine whether the drive is in a fault state, use the Drive Status function in DriveWare to view active and history event items and drive fault conditions. See the DriveWare Software Guide for more information on reading the Drive Status window. Some common fault conditions caused by hardware issues are listed below.

Over-Temperature Verify that the baseplate temperature is less than the maximum allowable baseplate temperature value. The drive remains disabled until the temperature at the drive baseplate falls below this threshold.

Over-Voltage Shutdown

1. Check the DC power supply voltage for a value above the drive over-voltage shutdown limit. If the DC bus voltage is above this limit, check the AC power line connected to the DC power supply for proper value.
2. Check the regenerative energy absorbed during deceleration. This is done by monitoring the DC bus voltage with a voltmeter or oscilloscope. If the DC bus voltage increases above the drive over-voltage shutdown limit during deceleration or regeneration, a shunt regulator may be necessary. See [“Power Supply Specifications” on page 15](#) for more information.

Under-Voltage Shutdown Verify power supply voltage for minimum conditions per specifications. Also note that the drive will pull the power supply voltage down if the power supply cannot provide the required current for the drive. This could occur when high current is demanded and the power supply is pulled below the minimum operating voltage required by the drive.

Short Circuit Fault

1. Check each motor lead for shorts with respect to motor housing, power ground, and also phase-to-phase. If the motor is shorted it will not rotate freely when no power is applied while it is uncoupled from the load.
2. Disconnect the motor leads to see if the drive will enable without the motor connected.
3. Measure motor armature resistance between motor leads with the drive disconnected.

Invalid Hall Sensor State See the "Commutation Sequence" table in ["Incremental Encoder Feedback" on page 8](#) for valid commutation states. If the drive is disabled check the following:

1. Check the voltage levels for all the Hall sensor inputs.
2. Make sure all Hall Sensor lines are connected properly.

B.1.1 Software Limits

Because DriveWare allows user configuration of many system parameters such as current, velocity, and position limits, as well as an associated "event action" for DriveWare to take when the system reaches this limit, it is possible for a drive to appear to be inoperative when in actuality it is simply in an assigned disable state.

For example, the motor velocity can be limited by giving a value to the Motor Over Speed selection in DriveWare. An "event action", such as "Disable the Power Bridge", can also be assigned for DriveWare to take if the motor reaches this speed. If the motor does happen to reach this velocity limit, DriveWare will automatically cut power to the drive's output in this particular case, and the drive will be disabled. In the Drive Status window, "Motor Over Speed" will be shown as a "history" event, and "Commanded Disable" will be shown as an "Action" event.

Depending on each specific system and application, there are many different options available for assigning system limits and associated actions. See the DriveWare Software Guide for more information.

B.1.2 Connection Problems

Connection problems are oftentimes caused by incorrect communication settings in DriveWare. The default factory setting for DZ drives is a Drive Address of 63 and 115200 Baud Rate. When connecting to the drive with DriveWare for the first time, these default factory settings will have to be used along with the appropriate serial port being used with the PC. Once the connection has been established, the Drive Address and Baud Rate may be changed. Check all communications settings to be sure that the Drive Address, Baud Rate, and serial port are correct. If unable to determine the appropriate settings, the Auto Detect routine will automatically scan for serial port and Baud Rate settings.

Faulty connection cables are also a possible cause of connection problems. Check all cables for any shorts or intermittent connections.


B.1.3 Overload

Verify that the minimum inductance requirement is met. If the inductance is too low it could appear like a short circuit to the drive and thus it might cause the short circuit fault to trip. Excessive heating of the drive and motor is also characteristic of the minimum inductance requirement not being met. See drive data sheets for minimum inductance requirements.

B.1.4 Current Limiting

All drives incorporate a “fold-back” circuit for protection against over-current. This “fold-back” circuit uses an approximate “ I^2t ” algorithm to protect the drive. All drives can run at peak current for a maximum of 2 second (each direction). Currents below this peak current but above the continuous current can be sustained for a longer time period, and the drive will automatically fold back at an approximate rate of “ I^2t ” to the continuous current limit within a time frame of less than 10 seconds. An over-current condition will not cause the drive to become disabled unless configured to do so in DriveWare.

FIGURE B.1 Peak Current Fold-Back



B.1.5 Motor Problems

A motor run-away condition is when the motor spins rapidly with no control from the command input. The most likely cause of this error comes from having the feedback element connected for positive feedback. This can be solved by changing the order that the feedback element lines are connected to the drive, or by using DriveWare to reverse the internal velocity feedback polarity setting.

Another common motor issue is when the motor spins faster in one direction than in the other. This is typically caused by improper motor commutation or poor loop tuning. Follow the steps in the DriveWare Software Guide to properly commutate and tune the motor.

B.1.6 Causes of Erratic Operation

- Improper grounding (i.e., drive signal ground is not connected to source signal ground).
- Noisy command signal. Check for system ground loops.
- Mechanical backlash, dead-band, slippage, etc.
- Noisy inhibit input line.
- Excessive voltage spikes on bus.

B.2 Technical Support

For help from the manufacturer regarding drive set-up or operating problems, please gather the following information.


B.2.1 Drive Model Information

- DC bus voltage and range.
- Motor type, including inductance, torque constant, and winding resistance.
- Length and make-up of all wiring and cables.
- If brushless, include Hall sensor information.
- Type of controller, plus full description of feed back devices.
- Description of problem: instability, run-away, noise, over/under shoot, or other description.
- Complete part number and serial number of the product. Original purchase order is helpful, but not necessary.

B.2.2 Product Label Description

The following is a typical example of a product label as it is found on the drive:

FIGURE B.2 Product Label



1. **Model Number:** This is the main product identifier. The model number can have a suffix designating a change from the base model.
2. **Revision Letter:** Product revision level letter ('A' is the earliest release from any model).
3. **Version:** The version number is used to track minor product upgrades with the same model number and revision letter ('01' is the earliest release of any revision).
4. **Proto Designation:** When included, indicates that the model is a prototype unit and model number will also begin with an 'X' designator.
5. **Serial Number:** The serial number consists of a 5-digit lot number followed by a 4-digit sequence number. Each product is assigned a unique serial number to track product life cycle history.
6. **Date Code:** The date code is a 4-digit number signifying the year and week of manufacture. The first two digits designate the year and the second two digits designate the week (e.g. the drive label shown would have been built in the year 2011 during the 18th week).
7. **General Information:** Displays applicable agency approvals, UL file reference number, compliance approvals. More complete product information is available by following the listed website.

B.2.3 Warranty Returns and Factory Help

Seller warrants that all items will be delivered free from defects in material and workmanship and in conformance with contractual requirements. The Seller makes no other warranties, express or implied and specifically NO WARRANTY OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE.

The Seller's exclusive liability for breach of warranty shall be limited to repairing or replacing at the Seller's option items returned to Seller's plant at Buyer's expense within one year of the date of delivery. The Seller's liability on any claim of any kind, including negligence, for loss or damage arising out of, connected with or resulting from this order, or from the performance or breach thereof or from the manufacture, sale, delivery, resale, repair or use of any item or services covered by or furnished under this order shall in no case exceed the price allocable to the item or service or part thereof which gives rise to the claim and in the event Seller fails to manufacture or deliver items other than standard products that appear in Seller's catalog. Seller's exclusive liability and Buyer's exclusive remedy shall be release of the Buyer from the obligation to pay the purchase price. IN NO EVENT SHALL THE SELLER BE LIABLE FOR SPECIAL OR CONSEQUENTIAL DAMAGES.

Buyer will take all appropriate measures to advise users and operators of the products delivered hereunder of all potential dangers to persons or property, which may be occasioned by such use. Buyer will indemnify and hold Seller harmless from all claims of any kind for injuries to persons and property arising from use of the products delivered hereunder. Buyer will, at its sole cost, carry liability insurance adequate to protect Buyer and Seller against such claims.

All returns (warranty or non-warranty) require that you first obtain a Return Material Authorization (RMA) number from the factory.

Request an RMA number by:

telephone	(805) 389-1935
fax	(805) 389-1165
web	www.a-m-c.com/download/form/form_rma.html

Numerics

10 V Analog Input.....	12
10 VDC Position Feedback.....	11

A

Address Line Inputs	29
Agency Compliances	ii
Altitude.....	16, 47
Ambient Temperature Range .	16, 48
AMP STATUS LED	40
Analog Inputs.....	30
Attention Symbols	iii
Auto Detect.....	51
AutoCommutation	44
Auxiliary Encoder.....	12
Auxiliary Encoder Inputs	30

B

Baseplate Temperature Range	16, 47
Baud Rate	51

C

Capacitive Interference	22
Capture Inputs	30
Central Point Grounding	21
Command Sources	12
10V Analog.....	12
Encoder Following.....	12
Communication Protocol	6
Communication Settings.....	51
Communication Wires	24
Commutation	42, 44–46
AutoCommutation	44
Manual Commutation.....	44
Sinusoidal.....	44
Trapezoidal	45
Commutation Sequence Table	46
Company Website.....	ii
Connection Problems.....	51
Control Modes.....	7
Current	7
Hall Velocity	7
Position	7
Velocity	7
Control Specifications	5
Current	7
Current Limiting	52

D

DC Bus Over Voltage Limit	5, 47
DC Bus Under Voltage Limit	5, 47
DC Power Input.....	34
DC Supply Voltage Range	5, 47
Differential Inputs	22
Digital Inputs (High Speed)	30
Digital Inputs (Standard)	29
Digital Outputs.....	30
Drive Address.....	51
Drive Datasheet	14
DriveWare	4, 41, 42
Dwell Time	14

E

Electromagnetic Interference	22
Encoder Feedback	8
Encoder Following.....	12
Encoder Index.....	8
Encoder Inputs	32
Environment	16
Shock/Vibration	17
Error Signal	8
External Filter Card	15, 22

F

Fault Conditions.....	50–52
Invalid Hall Commutation.....	51
Over-Temperature	50
Over-Voltage Shutdown	50
Short Circuit Fault	51
Under-Voltage Shutdown	50
Feedback Polarity	8
Feedback Supported.....	8–11
10 VDC Position	11
Encoder	8
Hall Sensors	8
Feedback Wires	23
Ferrite Suppression Cores	20
Firmware	46
Fold-back.....	52

G

Gearing Ratio	12
Ground Loops	21, 23
Grounding	21
Controller Chassis.....	21

Drive Case.....	21
Motor Chassis.....	21
PCB Interface Chassis.....	21
Power Supply Chassis.....	21
Shielding.....	21

H

Hall Sensor Inputs	8, 31
Hall Velocity	7
Hand Soldering	28
Humidity.....	16, 47

I

Impedance.....	22
Inductive Filter Cards	20
Input Reference Wires.....	24
Input/Output Pin Functions	
Analog Input.....	43
Auxiliary Encoder	33
Digital Inputs	43
Digital Outputs.....	43
Interface Circuitry Examples	29
Interference Coupling	22
Internal Bus Capacitance	5, 47
Invalid Hall Commutation	51

L

Lock-out/tag-out Procedures	1
Logic Supply Input.....	34

M

Magnetic Interference	22
Manual Commutation	44
Mating Connectors	27, 28
Max. Continuous Current	5, 47
Max. Peak Current	5, 47
Maximum Power Dissipation	
at Continuous Current.....	5, 47
Minimum Load Inductance.....	5, 47
Model Information.....	53
Model Mask	5
Motor "Run-Away"	8, 52
Motor Back EMF Constant	15
Motor Current	14–16
Motor Data	42
Motor Inductance	3, 15
Overload	52

Motor Line-to-Line Resistance	15	Peak Current Fold-back.....	52	Power Supply	15
Motor Power Output	35	Physical Dimensions	48	System Voltage Requirement.....	15
Motor Run-Away	52	Position.....	7		
Motor Specifications	14	Position Control	8	T	
Motor Speed.....	15	Encoder	8	Technical Support.....	53
Motor Torque Constant.....	14	Position Feedback, 10 VDC	11	Thermal Data	16–??, 48
Motor Voltage.....	15, 16	Positive Feedback	8	Torque.....	14
Motor Wires	22	Power Ground	21	Trace Routing.....	27
Mounting.....	25–28	Power Specifications	5	Trace Width.....	27
PCB Mounting Options.....	27	Power Supply Capacitance.....	3, 23	Trademarks	ii
Mating Connectors	27	Power Supply Output Current	16	Trapezoidal Commutation	45
Screw Mounting.....	28	Power Supply Specifications.....	15	Troubleshooting	50–54
Soldering	28	Power Supply Wires	23	Twisted Pair Wires	22
Mounting Card.....	25	Product Label.....	53		
Mounting Dimensions	49	Products Covered	5	U	
Move Profile	14, 16	Protective Earth Ground	21	Under-Voltage Shutdown	50
		PWM and Direction Inputs	30	User Units	42
N					
Negative Feedback.....	8	R		V	
Noise.....	22	Regeneration.....	15	Velocity	7
Nominal Power Supply Voltage	16	Returns	54	Velocity Control	8
		Revision History	iii	Encoder	8
O				Hall Sensors	10
Operation	41	S		Voltage Drop Interference.....	22
Overload	52	Safety	1–3		
Over-Temperature	16, 50	Screw Mounting.....	28	W	
Over-Voltage Shutdown	50	Selective Wave Soldering	28	Warning Symbols.....	iii
		Shielding.....	21, 22	Warranty Info	54
P		Shock/Vibration	17	Warranty Returns.....	54
Part Numbering Structure	5	Short Circuit Fault	51	Wave Soldering	28
PCB Design	27	Shunt Regulator	15	Wire Diameter	22
Circuitry Examples	29	Signal Ground	21	Wire Gauge	22
Address Line Inputs	29	Sinusoidal Commutation.....	44	Wiring.....	22–24
Analog Inputs.....	30	Software Limits.....	51	Communication Wires.....	24
DC Power.....	34	Soldering	28	Feedback Wires.....	23
Digital Inputs	29, 30	Space Vector Modulation	4	Impedance.....	22
Digital Outputs.....	30	Specifications Tables	47	Input Reference Wires.....	24
Encoder	32	Step and Direction Inputs	30	Motor Wires	22
Hall Sensors	31	Switching Frequency	5, 47	Power Supply Wires	23
Logic Supply	34	System Requirements	14–17	Wire Gauge	22
Motor Power.....	35	Environment	16		
Trace Routing.....	27	Motor	14		
Trace Width.....	27				
PCB Mounting Options.....	27				
PE Ground	21, 34, 35				

DZM Digital Drives
Hardware Installation Manual
MNDGZMIN-02



3805 Calle Tecate • Camarillo, CA 93012-5068
Tel: (805) 389-1935 Fax: (805) 389-1165 www.a-m-c.com